COSMOS

FS-1515 Rotor-Paddle-Wheel Flow Senser

MODEL FS-1515



YANGTECH TECHNOLOGY CO., LTD. (TAIWAN)

COSMOS FM-1515 ROTOR-PADDLEWHEEL FLOW SENSER OPERATION GUIDE

CE


SAFTY INSTRUCTIONS


- Consult the operation manual before installation and/or service.
- Do not remove from pressurized lines.
- Do not exceed maximum temperature and pressure specifications.
- Wear safety goggles and faceshield during installation and service.
- Do not alter product construction.
- Failure to follow safety instructions could result in severe personal injuryl.



SENSOR MOUNTING POSITIONS


- When horizontal pipe runs: Mount this sensor in up-right position is essential. When air bubbles are present, 45° of opposite side is limited.
- Do not mount on the bottom of the pipe when sediments are present.
- When Vertical pipe runs: Sensor must be mounted in lines with upward flow only.







LOCATION OF FITTINGS

- Recommended sensor upstream/downstream mounting requirements.
- A.Flange B.Valve/Gate C.Reducer D.2*90° elbow(3-dimensions) E.90° elbow F.2*90° elbow









SYSTEM CONSTRUCTION


- Use 2-conductor shielded cable for cable extensions up to 80 meter.(when cable longer than 80m it needs signal ampilifer)
- The sensor's connector is IP65 certified, 6.0mm diameter cable is needed.
- Cable shield must be maintained through cable splice





SENSOR INSTALLATION


- 1. Lubricate the sensor O-rings with silicone lubricant(e.g. GE silicone #G632 or equivalents). Do not use any petroleum based lubricant that will attack the O-ring.
- 2. Using an alternating/twisting motion to lower into the fitting. Make sure the alignment tab match the fitting notch.
- 3. Hand tighten the sensor cap. (Do not use any tighten tool)
- 4. Install display/control unit and establish the connections.





FITTINGS


A(strap-on saddles) B.(fusion-on saddles) C(strap-on saddles)














Discp.\Type	TYPE-A	TYPE-B	TYPE-C	TYPE-D
Materials	saddle plate :SUS304 U-type fitting:SUS304 Sensor base:PVC,PP;HDPE	Sensor base: PVC	U-type fitting:SUS304 Sensor base:PVC,PP;HDPE	Sensor base: PVC,PP
Available diameters	3.0" 4.0" 5.0" 6.0" 8.0'	3.0" 4.0" 5.0" 6.0" 8.0'	1.5" 2.0" 3.0"	1.5" 2.0" 3.0" 4.0" 6.0'
Maxmiun Pressure(kg/cm2)	6.0	3.0	6.0	6.0
Direct installation function	Yes	Yes	Yes	No

- If the pipe is made of PVC\PP\HDPE, use Type-B (thick pipe) to reduce deviation.
- TYPE-A,B,C is designed to be directly install, there is no need of disassemble of pipe:
 - 1. Stop running and drain out the pipe.
 - 2. Clean up the surface of the pipe where the detector will be installed.
 - 3. Drill a hole of 38-40mm in diameter then clean the holed area thoroughly.
 - 4. Smear PVC glue on the joint and pipe. (See right illustration)
 (For installation in metal pipe, use silicon glue instead of the PVC glue.)
 - 5. Use saddle plate and U-type fitting to fix the sensor (TYPE-A,C) •
 - 6. Use welding rod (of same material with the pipe) to weld the fusion saddle on the pipe.(TYPE-B , professional skill may needed) $^{\circ}$



- 1. Stop running and drain out the pipe.
- 2. Clean up the surface of the pipe where the detector will be installed.
- 3. Use proper glue to smear over the joint area. (See down illustration)
- 4. Insert the pipe into the glue-on tees for both side to complete the installation.





K-FACTOR

- The K-factor is the number of pulses the sensor will generate for each engineering unit of fluid passes. They are listed in unit of pulses/litters.
- The K-factor should input into a proper display/controller to achieve a correct result.

Pipe Diameter	Disp. High	Count Time	Input Signal High	K-Factor
(inch)	dsph	c.time	inhi	
	(m3/hr)	(sec)	(p/sec)	(pulse/litter)
2.0"	2.2~36.8	3600	142.17	13.908
3.0"	5.2~86.0	3600	142.03	5.947
4.0"	8.5~141.4	3600	142.10	3.618
5.0"	13.3~220.9	3600	142.07	2.315
6.0"	18.6~310.0	3600	142.21	1.651

SPECIFICATIONS

Flow rate range: 0.3-5.0 m/sec
Linearity: 2% of maximum range
Repeatability: 1.0% of maximum range

• Cable:2-conductor twisted pair with shield, below 80 meters with no amplification

● Operation temperature:10-60 °C

Power source: DC 6-24V
 Source impedance: 8k Ω
 Output: digital of Max.5.0 Volts
 Quality standard: FM,CE

A product of

COSMOS SCIENTIFIC COMPANY.